



USER MANUAL

UM10W WALL MOUNT GUN CLEANER



CAUTION

**DO NOT USE WATER BORNE UNITS WITH SOLVENT BORNE PAINT
OR
SOLVENT BORNE UNITS WITH WATER BORNE PAINT**

UNI-RAM CORPORATION • ONTARIO • CANADA

INTRODUCTION

Uni-ram holds many patents on designs used in its innovative products. Every machine is tested for compliance with Quality Assurance standards. Follow the directions in this manual under Setup, Operation and Maintenance in order to operate this machine safely and effectively. Not following these instructions can lead to malfunction or damage to the machine. Follow directions under the section below, Cautions and Warnings and on labels attached to the machine. Ensure that the manual is readily available to the operator at all times. If you have any questions about the operation of this machine, call your distributor or a Uni-ram Service Engineer:

North America: Uni-ram Technical Service 1-800-417- 9133

Other Continents: Contact Your Supplier

SETUP

INSPECTION

- Report any transport damage immediately to the carrier and your vendor. Initiate a freight claim with the carrier. The manufacturer is not responsible for freight damage.
- Accessories:
 - Manual
 - Air Blow Gun
 - Whip Line Coupler

PLACEMENT AND AIR SUPPLY

- Mount the unit to a wall (hardware not included) in a Spray Booth or another convenient location in the shop.
- Remove the cover on the "Air Input" (right side of machine) and attach an air supply adapter (not supplied).

Waterborne Models

- Attach the Whip Air Line Coupler (left side of machine) to your spray gun using a quick connect fitting (not supplied) on the Spray Gun.
- Remove the Air Blow Gun from the accessories bag and place it onto the bracket on the right side of the unit. Connect the air supply tube (blue) to the Air Blow Gun Fitting by inserting the tube. To disconnect the tube, push down on the collar and pull the tube out.

CAUTION

- The air supply must be free from contaminants such as water, dust, rust, tar, grease etc.
- To prevent damage to the Diaphragm Pump an internal Air Pressure Regulator has been installed to limit the air pressure. The pressure must be maintained at 60 PSI for waterborne units and 85 PSI for the UM80S. Do not install a second air pressure regulator.

PAIL SETUP

Two 5-litre bottle-type containers are included with the unit.

- Fill one container with clean water.
- Insert the suction tube (thin) into this container.
- Insert the drain tube (thick) into the other, empty, container.
- Place both containers under the unit.

CLEANING SPRAY GUNS

- Connect the spray gun to the whip air line or leave it connected to the main air supply line.
- To clean the paint channel, press the opening of the paint channel against the Cleaning Nozzle, squeeze the trigger, then press and HOLD the "Press To Clean Button". Hold the gun and Button in this position for about 15 seconds while moving the gun up and down on the nozzle several times to improve the cleaning of the paint channel opening. Release the Button.
- Clean the Cap by rubbing it on the Flat Brush mounted on the inside of the tank.
- Use the Air Blow Gun to dry the outside of the spray gun.
- To dry the paint channel, squeeze the spray gun trigger.

CAUTION: MAKE SURE THE GUNS ARE COMPLETELY DRY AFTER USE



REPLACEMENT PARTS

DESCRIPTION	PART NUMBER
AIR BLOW GUN	102-7010
5-LITRE BOTTLE TYPE CONTAINER	103-8111B
WHIP LINE	102-3980
FLAT BRUSH	103-3992



Full Product Warranty

These Uni-ram products have been engineered and manufactured to high performance standards. Each unit has been subjected to detailed factory testing before shipment.

This product comes with a one-year full warranty from the date of purchase. Uni-ram Corporation reserves the right to repair or replace the unit, free of charge, to the original purchaser if a part is found to be defective in material or workmanship as determined by factory service personnel. The items listed below under "Conditions of Warranty" as consumables are not covered.

Uni-ram reserves the right to direct the customer to ship the unit collect to the Uni-ram factory or to an approved Service Center for repair using the Uni-ram Return Goods Procedure or to repair the unit on-site. To prevent damage in transport, the purchaser must ship the unit in the original packaging or use alternate adequate packaging. All units must be **shipped clean and dry**.

Diaphragm Pump:

We are pleased to advise that the warranty on the diaphragm pump, the heart of the spray gun cleaner, comes with a 2 year replacement warranty. If, in the unlikely event your diaphragm pump fails during the first two years of service, call Uni-ram Service at 1-800-417-9133. We will send you a new pump free of charge and arrange for the return of your original pump.

Conditions of Warranty:

As Uni-ram Corporation has no control over the working conditions or circumstances under which the purchaser stores, handles or uses the product, Uni-ram makes no warranty or claim, either expressed or implied with respect to this product's fitness for any purpose or the result to be obtained from its use. This condition applies to the sale of all products and no representative or distributor of Uni-ram Corporation has the authority to waive or change these conditions.

This warranty applies only to the original purchaser and does not apply if the unit has been misused, overloaded, neglected, altered or used for any purpose other than those specified in the operating and installation instructions. Deterioration due to normal wear is not covered by this warranty. Damage due to accident, transportation, fire, floods or acts of God is also not covered. Units whose serial numbers have been altered or removed are not covered. The warranty is invalid if unauthorized chemicals or solvents with acid content are used in this unit. Unauthorized attempts at self-repair or alterations by the owner also invalidate this warranty. Interior or exterior finishes are not covered by this warranty.

Consumable Items are not covered by this warranty.

This warranty replaces all other warranties expressed or implied by statute or otherwise.

To make a claim, call Uni-ram Service at 1-800-417-9133 and quote the serial number of the unit.